

Mounting instruction



www.ssb-electronic.com

Aircell[®] 7, Ecoflex[®] 7

N plug / Item no.: 7392

Required tools: 1 x cutter knife 1 x scissors 2 x open-ended spanner 16 mm 1 x soldering station + solder		1		Cut off cable tail right-angled.
2		3		Remove 6 mm of the outer jacket with the cutter knife.
Move the nut, clamping ring and rubber washer over the cable tail.		4		Mark out and remove the copper foil and the white dielectric foam with a cutter knife.
Bend copper braid upwards right-angled. Insert contact sleeve between copper foil and braid until stop. Cut off protruding braid. Move the rubber seal to the front, up to the contact sleeve.		5		
6		7		Tighten the clamping nut finger tight with two open-ended spanners 16 mm. A gap of 0,5 to 1,0 mm must still be visible between the nut and the connector housing!
Place the inner pin on the inner conductor and carefully solder it through the small hole. The prepared cable tail has to be inserted into the housing until stop.				