


# Mobile Antenna for Amateur Radio



## Operation Instructions

To use the antenna properly, read these instructions thoroughly before using it. Keep this manual carefully at hand for later use.

This antenna is for amateur use. Please transmit on the amateur bands.

### 1. Before using the antenna

To avoid inviting accidents, please follow the following notices.

① Nuts and screws can be loosened by vibration during driving. Be sure to check those fastening devices from time to time and refasten if necessary.

② Strong impact can cause to break the antenna and may invited accidents by falling the element. It is recommended to drive away from those obstacles such as branches.



③ Strong vibrations caused by diesel engines may damage the antenna. It is recommended to install the antenna at the location where has least vibrations as possible.

④ Touching the antenna during transmission may cause to electrify. Be sure to confirm to see if there is no one around the antenna if transmission is taking place while the car is parked.



⑤ Don't drive a car with the antenna tilted. Driving the car with the antenna tilted may cause serious human accident.

### 2. How to install

Be sure to take those things such as local traffic regulations, and physical length of the car in account, and especially it has to be installed the location where is not easily reachable by people.

### 3. Notice

Don't transmit when the antenna is dirty. Otherwise the antenna show poor performance and the transceiver should have troubles.

Wipe the antenna with a piece of cloth from time to time.

Don't use thinner or benzene to clean the antenna. Use water thinned neutral detergent.

■ Though the product being purchased is manufactured under strict quality control, if damage is caused by transporting, ask your dealer promptly.

■ Design and specification of these products will be changed for future improvement without advance notice.

## DIAMOND ANTENNA CORPORATION

Miyata Building, No.15-1, 1-chomé Sugamo, Toshimaku Tokyo, Japan 170-0002 TEL.03-3947-1411 FAX.03-3944-2981

Home Page <http://www.diamond-ant.co.jp>

E-mail [overseas@diamond-ant.co.jp](mailto:overseas@diamond-ant.co.jp)