

Alltrucker 0.8L 12V/24V Electric Kettle - User Manual

WARNING!

Before First Use:

- Before plugging the appliance into a power outlet, check the information on the rating plate.
- Before first use, clean the water reservoir. NEVER immerse the power cord, plug, or kettle in water or other liquids.
- Boil two full batches of water without using them.
- Always place the appliance on a flat, stable surface.
- Keep out of reach of children during operation; lid must be securely closed to avoid splashing.
- Never operate when empty.
- Fill water according to the indicator: MIN and MAX marks.
- Disconnect from power after use.

FOR YOUR SAFETY

- Do not immerse power cord, plug, or kettle in water or other liquids.
- Never use if damaged.
- Do not place on hot stove or in oven.
- Use only water.
- Use only as intended.
- Clean exterior with a soft damp cloth only, unplug first.
- Keep out of reach of children.
- Remove limescale regularly.

OPERATION

- On/Off Switch (0/I): Press "I" to start heating, "O" to stop. Indicator light shows operation.
- Automatic Shut-Off: Stops when water boils. Wait 3 min before reheating.
- Boil-Dry Protection: Activates if no water is inside.
- Thermal Fuse: Cuts power if protections fail.

SPECIAL NOTES

- Do not immerse appliance in water.
- Repairs only by authorized service.
- Manufacturer not liable for misuse.

BEFORE USE

Read manual carefully and keep for future reference.

TECHNICAL SPECIFICATIONS

24V Version: Voltage 24V, Power 300W, Capacity 0.8L

12V Version: Voltage 12V, Power 170W, Capacity 0.8L